powerfurl.

SELECTION GUIDE

Use the guide below to select the furling system that best suits your boat. Cross reference boat length, sail type, sail area and Safe Working Load (SWL)*

| Choose By Sail Type | | | | | |
|---------------------|----------------|----------------------|------------|---------------------------|--|
| Boat Length (ft) | Stuctural sail | Staysail - Storm Jib | Code 0 | Gennaker / A Spinnaker | |
| ≤ 42 | Contact us | PF1-PF3 | PF3 | PF1-PF3 | |
| ≤ 52 | Contact us | PF3-PF4 | PF4 | PF4 | |
| ≤ 65 | Contact us | PF4-PF6 | PF6 | PF6 | |
| ≤ 78 | Contact us | PF6-PF8 | PF8-PF10 | PF8-PF10 | |
| ≤ 90 | Contact us | PF10 | PF10-PF12 | PF10-PF12 | |
| > 90 | Contact us | Contact us | Contact us | Contact us | |

Choose By Max Sail Area / Safe Working Load

| powerfurl. | Gennaker/Code 0 Sail area (m2) | Staysail - Storm Jib Sail area (m2) | SWL(kg) |
|--------------------|-----------------------------------|--|---------|
| powerfurl.[one] | ≤ 60 | ≤ 20 | 1,500 |
| powerfurl.[three] | ≤ 100 | ≤ 35 | 3,000 |
| powerfurl.[four] | ≤ 140 | ≤ 50 | 4,500 |
| powerfurl.[six] | ≤ 200 | ≤ 65 | 6,000 |
| powerfurl.[eight] | ≤ 280 | ≤ 75 | 8,000 |
| powerfurl.[ten] | ≤ 350 | ≤ 80 | 10,000 |
| powerfurl.[twelve] | ≤ 450 | ≤ 85 | 12,000 |



*Only initial guidelines. Please contact us for tailored recommendations on how to choose and use our powerfurl. systems. A member of our team will offer a personalised advice based on your boat characteristics and specific sailing habits.

